

Accessori per serrande a tenuta (hand drive)



R 9




UTILIZZO:

- ✓ Per DLCZT solo con perno ø8.

USE:

- ✓ For DLCZT only ø8.

R 11




UTILIZZO:

- ✓ Per DLCZT.

USE:

- ✓ For DLCZT.

R 12



UTILIZZO:

- ✓ Per DLT-T101Z
- ✓ Per DLT-T151Z
- ✓ Per DLT-T201Z
- ✓ Per DLCZT.

USE:

- ✓ For DLT101Z
- ✓ For DLT151Z
- ✓ For DLT201Z
- ✓ Per DLCZT.